


23' Carolina Skiff – LA3331



Drain Plug location:



The drain plug is in the middle rear of the boat. It must be installed before the boat is put into the water and removed upon exit, at the boat launch.

How to use the drain plug:

- To install the drain plug: Push until threads catch and then turn clockwise until the plug is tight in the hole.
- To uninstall the drain plug: Turn the plug counter-clockwise until the plug is loose.

This plug is a screw style and stays in the plug hole even when it is loose.

DO NOT pull drain plug out of the hole once the plug has been unscrewed.

Fuel:

Location of Gas Fill:

On the port (left) side of the engine on the stern of the boat. There is a small button opposite the hinge to press to open the gas cap.



Fuel Card Location:

In the clear and yellow Plano case in the center console of the boat.



How to use the fuel card/fill tank:

1. Put the card into the chip reader and wait for prompt to put in user ID
2. Once prompted, put in ID
3. Put in registration number on side of boat for the mileage (ex.3331)
4. Take card out once prompted
5. At the fuel tank fill location, open the lid
6. Fill fuel tank up in the fuel fill location
7. One the tank is full close the lid
8. Replace pump nozzle

Trailing:

When putting boat back on trailer if vegetation is stuck in between boat and trailer refloat boat and make sure vegetation is cleared out before leaving launch.

If a trailer tire has a problem (flat, blow out, etc.) during the trip please change it with the spare tire located on the trailer, a jack and lug wrench are located in the trucks and the key for the lock on the spare tire will be located on the key ring for the boat; try all of the keys until you find the one that works. If this happens on a long trip and you wish to replace the bad tire it is okay to use a LaCarte card to purchase a replacement, just remember to keep the receipt and the shop will give you an account number to charge that purchase too.